


T25p Parts




<u>Front Frame I</u>	<u>1</u>	<u>Landing Gear</u>	<u>8</u>
<u>Front Frame II</u>	<u>2</u>	<u>Spray Tank</u>	<u>9</u>
<u>Middle Frame</u>	<u>3</u>	<u>Impeller Pump</u>	<u>10</u>
<u>Rear Frame</u>	<u>4</u>	<u>Flow Meter</u>	<u>11</u>
<u>Cable Distribution</u>	<u>5</u>	<u>Aircraft Arms</u>	<u>12</u>
<u>Propellers</u>	<u>6</u>	<u>Spray Lance</u>	<u>13</u>
<u>Cables</u>	<u>7</u>	<u>Avionics module</u>	<u>14</u>




1. Front Frame I

No.	Material Number	Material Name
1	YC.JG.ZS004476	Front Shell_Front Cover
2	YC.WJ.L00870	Screw M30-HC060060-55-85
3	YC.JG.ZS003452	Outer Shell Side Cover
4	YC.WJ.L00870	Screw M30-HC060060-55-85
5	YC.JG.ZS004477	Front Shell Module
6	YC.WJ.L00870	Screw M30-HC060060-55-85
7	FL.SC.BB000001	Acetate Fabric
8	YC.DZ.AA000326	SDR Antenna (Front)
9	YC.JG.ZS003455	RF Cable Clip
10	YC.ST.LL000235	T30-HC00800080-057030-5103-N
11	YC.JG.ZS000998	Buckle Base (Female)
12	YC.ST.LL000235	T30-HC00800080-057030-5103-N




2. Front Frame II

No.	Material Number	Material Name
1	YC.JG.ZS004593	Front Shell_Top Cover
2	YC.WJ.L00870	Screw M30-HC060060-55-85
3	YC.WJ.L00868	Screw M30-HC080080-55-85
4	BC.AG.SS000863	FPV Module (Incl. Signal Cable)
5	YC.WJ.L00870	Screw M30-HC060060-55-85
6	YC.ST.LL000122	Screw M25-HC00780040-040020-5108-N
7	YC.XC.XX001215	FPV Camera Signal Cable
8	YC.JG.MQ002494	Thermally Conductive Pad (71 x 51 mm)
9	YC.JG.MQ002497	Thermally Conductive Pad (35 x 27 mm)
10	YC.JG.YZ000805	Front Radar Bracket
11	YC.ST.LL000489	Screw M50-HC02000200-087052-4203-Y
12	YC.JG.ZS004582	Front Radar Base Bracket
13	YC.WJ.L00870	Screw M30-HC060060-55-85
14	YC.WJ.L00870	Screw M30-HC060060-55-85
15	YC.WJ.L00870	Screw M30-HC060060-55-85
16	YC.JG.MY001041	Radar Sealing Ring
17	YC.JG.YZ000803	Front Radar Base
18	BC.AG.SS001004	Front Radar Module (Incl. Signal Cable)
19	YC.XC.XX001212	Front Radar Signal Cable
20	YC.ST.LL000226	M30-HC01450080-100020-5103-Y
21	YC.JG.ZS003453	Propulsion Cable Clip
22	YC.WJ.L00873	Screw M30-HC1880-55-85
23	YC.ST.LL000122	Screw M25-HC00780040-040020-5108-N
24	See the branching component for details.	
25	YC.XC.XX001214	Binocular Vision Sensor Signal Cable
26	YC.JG.ZS005366	Female Connector Rubber Stopper
27	YC.ST.LL000122	Screw M25-HC00780040-040020-5108-N
28	YC.ST.LL000541	Screw M30-HC02380080-094020-5103-Y
29	YC.JG.MY001353	Binocular Vision Sensor Damping Pad
30	YC.JG.MQ002156	Duct Tape
31	BC.AG.SS000873	Binocular Fisheye Sensor (Incl. Signal Cable)
32	YC.XC.XX001208	Payload Adapter Cable
33	YC.JG.MY001453	Cable Rubber Stopper
34	YC.ST.LL000148	M40-HC01400140-070039-4105-Y
35	YC.JG.MY001079	Front Shell Sealing Stopper
36	YC.JG.MY001490	Front Shell Rubber Stopper
37	YC.JG.MQ002641	Sealing Foam (133.3 x 35.7 mm)
38	YC.JG.ZS004478	Front Shell Bottom Plate
39	YC.JG.MQ002642	Sealing Foam (59.5 x 19.3 mm)




3. Middle Frame

No.	Material Number	Material Name
1	YC.JG.ZS003467	Landing Gear Fixing Piece (Rear Right)
2	YC.ST.LL000482	Screw M40-HC01400140-070042-4203-Y
3	YC.JG.MY001051	Cable Tube Rubber Stopper
4	YC.JG.MY001050	Anti-Collision Pad
5	YC.JG.ZS004996	Hose Clip
6	YC.ST.LL000482	Screw M40-HC01400140-070042-4203-Y
7	YC.JG.ZS003413	Aircraft Arm Fixing Piece (Right)
8	YC.JG.ZS003602	Weighing Sensor Bracket Roller
9	YC.WJ.ZZ002618	Spray Tank Fixing Piece_Roller Shaft
10	YC.JG.ZS003599	Weight Sensor Bracket (Right)
11	YC.WJ.LL000232	M40-HC01000100-072028-5103-N_01
12	BC.AG.SS000864	Aircraft Frame Module
13	YC.JG.ZS003464	Landing Gear Fixing Piece (Front Right)
14	YC.JG.ZS004978	Extended Battery Supporting Piece (Right)
15	YC.JG.MQ001386	Battery Supporting Piece Patch (Right)
16	YC.JG.MY001402	Outer Scroll Wheel (Small)
17	YC.XJ.QT000247	Battery Fixing Piece_External Roller
18	YC.SJ.WS002500	Spray Tank Fixing Piece_Internal Roller
19	YC.WJ.ZZ002618	Spray Tank Fixing Piece_Roller Shaft
20	YC.JG.ZS004993	Inner Scroll Wheel (Small)
21	YC.ST.LL000480	Screw T20-PR01450045-035015-5103-N
22	YC.JG.JS000034	Cable Tube
23	YC.ST.LL000483	Screw M40-HC01000100-072042-4203-Y
24	YC.JG.MQ001385	Battery Supporting Piece Patch (Left)
25	YC.JG.ZS004979	Extended Battery Supporting Piece (Left)
26	YC.JG.ZS003465	Landing Gear Fixing Piece (Front Left)
27	YC.JG.ZS003589	Cable Clip
28	YC.JG.ZS003601	Weighing Sensor Bracket (Front)
29	YC.JG.ZS003600	Weight Sensor Bracket (Left)
30	YC.JG.ZS002229	Load Sensor Cable Clip
31	YC.JG.ZS003412	Aircraft Arm Fixing Piece (Left)
32	YC.JG.ZS003466	Landing Gear Fixing Piece (Rear Left)
33	YC.ST.LM000092	Nut (M40-HN068100-5103)
34	YC.ST.LL000537	Screw (M40-HC04000140-070040-5103-N)




4. Rear Frame

No.	Material Number	Material Name
1	YC.JG.ZS003395	Rear Shell Bottom Plate
2	YC.ST.LL000148	M40-HC01400140-070039-4105-Y
3	YC.JG.MY001071	Dustproof Stopper
4	YC.JG.MY001128	Cable Rubber Sleeve
5	YC.JG.ZS004834	Cable Clip
6	YC.WJ.LL000232	M40-HC01000100-072028-5103-N_01
7	YC.WJ.L00870	Screw M30-HC060060-55-85
8	YC.WJ.L00870	Screw M30-HC060060-55-85
9	YC.JG.ZS003452	Outer Shell Side Cover
10	YC.JG.ZS003397	Rear Shell Module
11	YC.JG.MY001054	Damping Pad
12	YC.ST.LL000335	Screw M30-HC01350050-140020-5103-Y
13	BC.AG.SS000695	Power Distribution Board Module
14	YC.JG.FM000122	Battery Buckle
15	YC.ST.LL000336	Screw (M30-HC100100-55-85)
16	YC.JG.ZS003588	Power Distribution Board Waterproof Cover
17	YC.ST.LL000382	Screw (M30-HC00550045-055012-5103-Y)
18	YC.JG.MY001073	RTK Rubber Ring
19	BC.AG.SS001034	RTK Antenna Module
20	YC.JG.ZS003396	Rear Cover of Rear Shell
21	YC.WJ.L00870	Screw M30-HC060060-55-85
22	YC.WJ.L00870	Screw M30-HC060060-55-85
23	YC.JG.ZS003443	Rear Shell_Lower Cover




5. Cable Distribution Board

No.	Material Number	Material Name
1	BC.AG.SS000861	Payload Control Board
2	YC.JG.QX002311	Damping Pad A
3	YC.JG.QX002312	Damping Pad B
4	YC.JG.MQ002623	Thermally Conductive Pad (53.1 x 12.9 mm)
5	YC.JG.MQ002463	Thermally Conductive Pad (125.35 x 27.7 mm)
6	YC.JG.MY001348	Aerial-Electronics Module Sealing Ring
7	YC.WJ.L00868	Screw M30-HC080080-55-85
8	BC.AG.SS001138	Aerial-Electronics System Module
9	YC.JG.MY001349	Barometer Curve Connector
10	YC.ST.LL000122	Screw M25-HC00780040-040020-5108-N
11	YC.WJ.LL000235	M20-HPW00600060-065016-5103-Y_02
12	YC.ST.LL000122	Screw M25-HC00780040-040020-5108-N
13	YC.JG.MY000389	Type-C Port Waterproof Cover




6. Propellers

No.	Material Number	Material Name
1	YC.JG.ZS005565	Teflon Pad
2	YC.ST.LL000209	M50-HF01430102-116041-0003-Y
3	YC.JG.MQ001280	Rubber Pad
4	YC.JG.QX002975	Propeller Clamp
5	YC.JG.ZS003553	Propeller (CW)
6	YC.JG.ZS003552	Propeller (CCW)
7	YC.JG.MQ002005	Propeller Fixing Piece



7. Cables

No.	Material Number	Material Name
1	YC.XC.DD000683	Battery Power Cable
2	YC.XC.XX001198	Throttle Cable
3	YC.XC.DD000680	Rear Aircraft Arm ESC Power Adapter Cable
4	YC.XC.XX001195	Battery Communication Cable
5	YC.XC.TT000179	RF Coaxial Cable
6	YC.DZ.AA000460	SDR Antenna (Rear)
7	YC.JG.MY001011	Weighing Sensor Rubber Cover
8	YC.XC.XX001213	Beacon Signal Cable
9	YC.XC.XX001198	Throttle Cable
10	YC.XC.DD000680	Rear Aircraft Arm ESC Power Adapter Cable
11	YC.XC.TT000179	RF Coaxial Cable
12	YC.DZ.AA000460	SDR Antenna (Rear)
13	BC.AG.SS000860	Weight Sensor Module



8. Landing Gear


No.	Material Number	Material Name
1	YC.WJ.L00870	Screw M30-HC060060-55-85
2	BC.AG.SS000877	Beacon
3	YC.JG.ZS004578	Beacon Bracket
4	YC.WJ.L00873	Screw M30-HC1880-55-85
5	YC.WJ.L00877	M3 Nut
6	YC.WJ.L00873	Screw M30-HC1880-55-85
7	YC.JG.ZS005117	Landing Gear Cable Clip B
8	YC.ST.LL000543	Screw T30-HC01000100-057030-5103-N
9	YC.WJ.L00871	Screw M30-HC100100-55-85
10	YC.WJ.L00877	M3 Nut
11	YC.JG.ZS003558	Bottom Rubber Pad
12	YC.JG.ZS005273	Landing Gear Crossbeam (Rear)
13	YC.JG.ZS003725	Landing Gear Cable Clip
14	YC.ST.LL000543	Screw T30-HC01000100-057030-5103-N
15	YC.ST.LL000122	Screw M25-HC00780040-040020-5108-N
16	YC.XC.XX001216	Rear Radar Signal Cable
17	YC.JG.MY001131	Rubber Pad
18	YC.WJ.L00870	Screw M30-HC060060-55-85
19	YC.WJ.L00873	Screw M30-HC1880-55-85
20	YC.JG.ZS004711	Radar Supporting Piece (Left)
21	BC.AG.SS001005	Rear Radar Module (Incl. Signal Cable)
22	YC.JG.MY001575	Anti-Wear Rubber Stopper
23	YC.JG.ZS003492	Radar Supporting Piece (Right)
24	YC.WJ.L00873	Screw M30-HC1880-55-85
25	YC.JG.BJ002268	Landing Gear Aluminum Tube



9. Spray Tank


No.	Material Number	Material Name
31	YC.JG.CS000017	Spray Tank (20L)
1	YC.BZ.RB000011	Spread Tank Lanyard

No.	Material Number	Material Name
2	YC.JG.ZS002250	Spray Tank Cover Waterproof Permeability Cover
3	YC.JG.MY000678	Spray Tank Cover Waterproof Permeability Film
4	YC.JG.MY000679	Spray Tank Cover Sealing Ring
5	YC.JG.ZS003393	Spray Tank Cable Clip
6	YC.WJ.L00876	Screw M40-HC060060-55-85
7	YC.WJ.L00876	Screw M40-HC060060-55-85
8	YC.JG.ZS003392	Impeller Pump Bracket
9	YC.JG.MY000687	Spray Tank Y-tee Part Sealing Ring
10	YC.JG.ZS002232	Spray Tank Y-tee Part
11	BC.AG.SS000471	Spray Tank Liquid Level Meter
12	YC.JG.ZS002237	Liquid Level Gauge Bracket
13	YC.WJ.L00876	Screw M40-HC060060-55-85
14	YC.SJ.WS002412	Spray Tank_Liquid Level Meter Installation Nut
15	YC.XJ.QT000194	Spray Tank_Liquid Level Meter Installation Nut
		Sealing Ring
16	BC.AG.SS000709	Liquid Level Gauge Sensor Module
17	See impeller pump for details	
18	YC.JG.ZS005365	Male Connector Rubber Stopper
19	YC.JG.MY000687	Spray Tank Y-tee Part Sealing Ring
20	YC.WJ.L00876	Screw M40-HC060060-55-85
21	YC.JG.ZS004712	Flow Meter Bracket
22	YC.JG.ZS005454	Filter With 50 Holes
23	YC.JG.ZS002233	Water Outlet Rotation Cover
24	YC.JG.ZS005453	Spray Tank Y-tee Part Nut
25	YC.SJ.J01186	Spray Tank_Filter Rubber Ring
26	YC.JG.MY000845	Spray Tank Y-tee Part Sealing Ring
27	YC.JG.ZS001085	Spray Tank Inlet Filter
28	YC.SJ.WS002423	Spray Tank_Spray Tank Cover Ring
29	YC.WJ.LL000211	M30-HC02050080-070020-5103-Y_01
30	YC.JG.ZS002251	Spray Tank Cover




10. Impeller Pump

No.	Material Number	Material Name
1	YC.JG.ZS004649	Pump Shell
2	YC.XJ.QT000350	Pump_Connector Sealing Ring
3	YC.JG.ZS003420	Impeller Pump Curving Connector
4	YC.JG.MY001327	Ceramic Rubber Pad
5	YC.JG.FM000157	Ceramic Gasket
6	YC.JG.ZS004667	Isolation Sleeve
7	YC.JG.MY001052	Pump Sealing Ring
8	BC.AG.SS000710	Impeller Pump Module
9	YC.XC.XX001209	Spray Tank Signal Cable
10	YC.JG.MY001315	Sealing Ring (OD=31.4 mm)
11	YC.WJ.L00870	Screw M30-HC060060-55-85
12	YC.JG.ZS002389	Impeller Pump Protective Hood
13	YC.ST.LL000454	Screw M30-HC00630050-050013-5103-Y
14	BC.AG.SS000870	Impeller Pump Motor
15	YC.JG.MY001316	Sealing Ring (OD=46.5 mm)
16	YC.JG.ZS002233	Water Outlet Rotation Cover
17	YC.JG.MY001053	Y-tee Part Sealing Pad




11. Flow Meter Module

No.	Material Number	Material Name
1	YC.JG.JS000033	Flow Meter Water Outlet Hose
2	YC.JG.ZS003594	Thumb Nut
3	YC.JG.ZS004721	One-Way Valve Core Straight Connector
4	YC.JG.ZS002255	Hose Nut
5	YC.JG.MY001129	One-Way Valve Sealing Ring
6	YC.JG.MY001329	One-Way Valve Core Sealing Ring
7	YC.JG.ZS005001	One-Way Valve Core
8	YC.JG.TT000210	One-Way Valve Spring
9	YC.JG.ZS004722	One-Way Valve Core Curve Connector
10	YC.XC.XX001004	Flow Meter Signal Cable
11	YC.JG.ZS002255	Hose Nut
12	BC.AG.SS000927	Flow Meter Module (Incl. Signal Cable)
13	YC.JG.JS000032	Flow Meter Water Inlet Hose
14	YC.JG.ZS003594	Thumb Nut




12. Aircraft Arm

No.	Material Number	Material Name
1	BC.AG.SS000867	M3 Aircraft Arm (Rear Left)
2	YC.JG.FP000039	Motor Cover
3	YC.XC.DD000678	M3 & M4 Aircraft Arm ESC Composite Cable
4	YC.WJ.LL000213	M30-HT01930060-110025-5103-Y
5	See spray boom for details	
6	YC.JG.ZS004019	In-Position Detector Bracket
7	YC.WJ.LL000232	M40-HC01000100-072028-5103-N_01
8	YC.ST.LL000544	Screw T25-HC00800080-045025-4203-N
9	YC.JG.LD000041	Locking Piece Fixing Screw Bolt
10	YC.WJ.LM000044	M60-HX100060-5103_01
11	YC.JG.LD000045	Aircraft Arm Fixing Screw Bolt
12	YC.JG.ZS003594	Thumb Nut
13	YC.WJ.LM000044	M60-HX100060-5103_01
14	YC.JG.BJ002409	E-Type Circlip (OD=6 mm)
15	YC.ST.LL000148	M40-HC01400140-070039-4105-Y
16	YC.JG.QX003014	Buckle Rotation Shaft
17	YC.JG.QX002089	Locking Piece Aircraft Arm Shaft
18	YC.JG.TT000165	Buckle Torsion Spring
19	YC.JG.QX003942	Locking Piece Connection Rod
20	BC.AG.SS000701	Buckle Module
21	YC.JG.BJ003468	Locking Piece Handle
22	YC.JG.QX004662	Locking Piece_Handle Connecting Rod Shaft
23	YC.JG.ZS006831	Locking Piece Handle Rubber Sleeve
24	YC.WJ.L00870	Screw M30-HC060060-55-85
25	BC.AG.SS000869	ESC Module
26	YC.ST.LL000122	Screw M25-HC00780040-040020-5108-N
27	YC.WJ.L01234	Screw M40-HC080080-68-85
28	YC.JG.JS000045	Aircraft Arm Hose
29	YC.ST.LL000208	M20-TC00700060-033010-0004-Y
30	YC.JG.ZS005501	Motor Upper Cover
31	YC.ST.LL000489	Screw M50-HC02000200-087052-4203-Y
32	YC.BZ.TZ001048	Motor Sticker
33	BC.AG.SS000706	10028 Propulsion Motor
34	YC.JG.ZS003460	Hose Nut (M15)
35	YC.JG.MY001465	Aircraft Arm Rubber
	YC.XC.DD000676	M1 & M2 Aircraft Arm ESC Composite Cable
	BC.AG.SS000865	M1 Aircraft Arm (Front Right)
	BC.AG.SS000866	M2 Aircraft Arm (Front Left)
	BC.AG.SS000868	M4 Aircraft Arm (Rear Right)



13. Spray Lance

No.	Material Number	Material Name
1	YC.JG.ZS004506	Spray Lance Shell
2	YC.JG.JS000043	Sprinkler Soft Hose
3	BC.AG.SS000871	Solenoid Valve Module
4	YC.JG.ZS004923	Centrifugal Sprinkler Lower Disk
5	YC.JG.TT000203	R-Type Pin
6	YC.JG.MY001295	Sealing Ring (ID=16.5 mm)
7	YC.JG.ZS004510	Centrifugal Sprinkler Nut
8	YC.JG.ZS004509	Centrifugal Sprinkler Upper Disk
9	BC.AG.SS000872	Centrifugal Motor
10	YC.WJ.LL000138	Screw M25-HC00400040-050020-0003-N
11	YC.WJ.L00870	Screw M30-HC060060-55-85
12	YC.JG.MY001296	Sprinkler Funnel Sealing Ring
13	YC.JG.ZS004512	Sprinkler Funnel
14	YC.WJ.LL000138	Screw M25-HC00400040-050020-0003-N
15	YC.JG.MY000704	Motor Sealing Ring
16	YC.JG.ZS004513	Sprinkler Funnel Lower Shell
17	YC.XC.XX001281	Centrifugal Sprinkler Adapter Cable
18	YC.WJ.L00870	Screw M30-HC060060-55-85



14. Avionics module

No.	Material Number	Material Name
1	YC.JG.MQ001996	Anti-Drop Foam (28 x 5.3 x 2.5 mm)
2	BC.AG.SS000925	Aerial Electronics Module Lower Shell (incl. RF Cable)
3	BC.AG.SS000907	IMU module
4	YC.WJ.LL000434	Screw M12-PC00400040-022005-3123-Y
5	BC.AG.PP000479	Aerial Electronics Board
6	YC.WJ.LL000304	Screw M20-PC00400040-040010-3123-Y
7	YC.JG.YZ000795	Aerial Electronics Module Upper Cover
8	YC.ST.LL000192	Screw M25-HC00400040-047025-0003-Y
9	YC.SJ.S00717	Vent Trap
10	YC.JG.MY001348	Aerial-Electronics Module Sealing Ring
11	YC.PM.QT000137	Barometer Protection Foam
12	YC.WJ.LL000396	Screw (T20-PC00400040-040010-0323-N)
13	BC.AG.PP000520	Barometer Board
14	YC.JG.MY000699	Barometer Module Sealing Ring
15	YC.JG.ZS002301	Barometer Outer Shell
16	YC.WJ.L00868	Screw M30-HC080080-55-85
17	YC.QT.QT000167	Barometer Waterproof Permeability Film
18	YC.XC.XX001238	Barometer Module Cable
19	YC.JG.MQ001253	Anti-Drop Foam A