


T50 Parts




Front Cover Shell	1	Tank II	9
Front Frame	2	Impeller Pump	10
Middle Frame	3	Flow Meter Module	11
Rear Frame	4	M1 Aircraft Arm	12
Landing Gear	5	M3 Aircraft Arm	13
Cable Distribution	6	Spray Lance	14
Cables	7	Propeller	15
Tank I	8		



1. Front Cover of Front Shell


No.	Material Number	Material Name
1	YC.JG.MY001043	Auxiliary Bottom Light Sealing Ring
2	BC.AG.SS000677	Auxiliary Bottom Light Module
3	YC.WJ.L00870	Screw M30-HC060060-55-85
4	YC.ST.LL000235	T30-HC00800080-057030-5103-N
5	YC.JG.ZS000998	Buckle Base (Female)
6	YC.JG.ZS003386	Front Cover of Front Shell
7	YC.XC.XX000999	Auxiliary Bottom Light Signal Cable




2. Front Frame

No.	Material Number	Material Name
1	YC.WJ.L00870	Screw M30-HC060060-55-85
2	YC.DZ.AA000326	SDR Antenna (Front)
3	YC.ST.LL000122	Screw M25-HC00780040-040020-5108-N
4	YC.XC.XX001013	Forward Vision Sensor Signal Cable
5	YC.JG.MY001038	Damping Silicone Rubber
6	BC.AG.SS000671	Forward Vision Sensor Module
7	YC.ST.LL000226	M30-HC01450080-100020-5103-Y
8	YC.ST.LL000235	T30-HC00800080-057030-5103-N
9	YC.JG.ZS003455	RF Cable Clip
10	YC.JG.ZS003389	Top Cover of Front Shell
11	YC.JG.YZ000671	Forward Radar Bracket
12	YC.JG.QX003038	FPV Camera Bracket Supporting Piece
13	YC.ST.LL000013	Screw M40-HC01400140-070039-0003-Y
14	YC.WJ.LL000232	M40-HC01000100-072028-5103-N_01
15	YC.WJ.LL000232	M40-HC01000100-072028-5103-N_01
16	YC.ST.LL000228	M20-PC00400040-040010-5103-Y
17	YC.JG.ZS003435	Auxiliary Arm
18	YC.JG.MY000985	Lens Cap Sealing Gasket
19	BC.AG.SS000682	Lens Cap Module
20	YC.WJ.L00870	Screw M30-HC060060-55-85
21	BC.AG.SS000681	FPV Camera Module
22	YC.JG.MY001079	Front Shell Sealing Stopper
23	YC.ST.LL000148	M40-HC01400140-070039-4105-Y
24	YC.JG.ZS003388	Front Shell Bottom Plate
25	BC.AG.SS000672	Front Frame Aluminum Tube
26	YC.JG.ZS003425	FPV Camera Bracket
27	YC.WJ.LL000232	M40-HC01000100-072028-5103-N_01
28	YC.WJ.L00870	Screw M30-HC060060-55-85
29	YC.JG.MY001044	Binocular Vision Sensors Sealing Ring
30	YC.WJ.L00870	Screw M30-HC060060-55-85
31	YC.JG.ZS003452	Outer Shell Side Cover
32	YC.JG.ZS003387	Front Shell Module
33	YC.JG.MY001041	Radar Sealing Ring
34	YC.JG.YZ000672	Forward Radar Base
35	YC.JG.MY001042	Radar Base Sealing Ring
36	BC.AG.SS000939.02.F	Forward Radar Module
37	YC.XC.XX001011	Forward Radar Signal Cable
38	YC.JG.ZS003493	Radar Left Supporting Piece
39	YC.JG.ZS003492	Radar Right Supporting Piece
40	BC.AG.SS000940.02.F	Rear Radar Module
41	YC.XC.XX001012	Rear Vision Radar Signal Cable

3. Middle Frame




No.	Material Number	Material Name
1	YC.JG.ZS003438	Battery Supporting Piece (Left)
2	YC.WJ.LL000232	M40-HC01000100-072028-5103-N_01
3	YC.JG.MQ001385	Battery Supporting Piece Patch (Left)
4	YC.SJ.WS002500	Spray Tank Fixing Piece_Internal Roller
5	YC.XJ.QT000247	Battery Fixing Piece_External Roller
6	YC.WJ.ZZ002618	Spray Tank Fixing Piece_Roller Shaft
7	BC.AG.SS000685	M3 Aircraft Arm Connector
8	BC.AG.SS000687	Middle Frame Aluminum Tube (Left)
9	YC.JG.ZS003589	Cable Clip
10	YC.JG.QX003017	Middle Frame Insert Part
11	YC.JG.ZS003479	Hose Clip
12	YC.JG.MY001051	Cable Tube Rubber Stopper
13	YC.JG.JS000035	Cable Tube
14	BC.AG.SS000688	Middle Frame Aluminum Tube (Right)
15	BC.AG.SS000686	M4 Aircraft Arm Connector
16	YC.JG.MQ001386	Battery Supporting Piece Patch (Right)
17	YC.JG.ZS003439	Battery Supporting Piece (Right)
18	YC.JG.ZS003599	Weighing Sensor Bracket (Right)
19	YC.JG.ZS003463	Aircraft Arm Fixing Piece (Right)
20	BC.AG.SS000683	M1 Aircraft Arm Connector
21	YC.JG.ZS003601	Weighing Sensor Bracket (Front)
22	YC.JG.ZS002229	Load Sensor Cable Clip
23	YC.ST.LL000327	Screw (M40-HC01050056-070039-5103-Y)
24	BC.AG.SS000684	M2 Aircraft Arm Connector
25	YC.JG.ZS003462	Aircraft Arm Fixing Piece (Left)
26	YC.ST.LL000148	M40-HC01400140-070039-4105-Y
27	YC.JG.MY001055	Anti-Collision Pad
28	YC.JG.ZS003600	Weighing Sensor Bracket (Left)
29	YC.JG.ZS003602	Weighing Sensor Bracket Roller
30	YC.WJ.LL000232	M40-HC01000100-072028-5103-N_01
31	YC.WJ.ZZ002618	Spray Tank Fixing Piece_Roller Shaft




4. Rear Frame

No.	Material Number	Material Name
1	YC.JG.ZS003396	Rear Cover of Rear Shell
2	YC.JG.ZS003443	Lower Cover of Rear Shell
3	YC.WJ.L00870	Screw M30-HC060060-55-85
4	YC.JG.ZS003395	Rear Shell Bottom Plate
5	YC.WJ.LL000232	M40-HC01000100-072028-5103-N_01
6	YC.JG.MY001058	Rear Shell Sealing Stopper
7	BC.AG.SS000690	Spraying Power Module
8	YC.WJ.LL000232	M40-HC01000100-072028-5103-N_01
9	BC.AG.SS000691	Power Distribution Board Module
10	YC.JG.MY001054	Damping Pad
11	YC.ST.LL000335	Screw (M30-HC01150050-120020-5103-Y)
12	YC.XC.XX001001	Spraying Adaptive Cable
13	BC.AG.SS000692	Rear Frame Aluminum Tube
14	YC.JG.MY001057	Adaptive Cable Rubber Sleeve
15	YC.JG.FM000122	Battery Buckle
16	YC.ST.LL000336	Screw (M30-HC100100-55-85)
17	YC.JG.ZS003588	Power Distribution Board Waterproof Cover
18	YC.ST.LL000382	Screw (M30-HC00550045-055012-5103-Y)
19	YC.JG.MQ001973	Glue Baffle Plate
20	BC.AG.SS000694	RTK Antenna Module
21	YC.WJ.L00870	Screw M30-HC060060-55-85
22	YC.JG.ZS003452	Outer Shell Side Cover
23	YC.JG.MY001073	RTK Rubber Ring
24	YC.WJ.L00870	Screw M30-HC060060-55-85
25	YC.JG.ZS003397	Rear Shell Module

5. Landing Gear




No.	Material Number	Material Name
1	YC.JG.BJ001821	Landing Gear Aluminum Tube
2	YC.WJ.L00873	Screw M30-HC1880-55-85
3	YC.JG.ZS003558	Landing Gear Bottom Rubber Pad
4	YC.WJ.L00877	M3 Nut
5	YC.WJ.L00871	Screw M30-HC100100-55-85
6	YC.WJ.L00877	M3 Nut
7	YC.JG.ZS003468	Landing Gear Y-tee Part
8	YC.WJ.LL000426	T30-HC01000100-057030-0323-N
9	YC.ST.LL000017	Screw M30-HC02800070-055030-0003-Y
10	YC.JG.ZS003725	Landing Gear Cable Clip
11	YC.JG.XW000110	Landing Gear Crossbeam (Rear)
12	YC.JG.ZS003467	Landing Gear Fixing Piece (Rear Right)
13	YC.ST.LL000339	Screw (M40-HC03500120-070040-5103-N)
14	YC.WJ.L00961	M4 Stainless Locknut
15	YC.ST.LL000330	Screw (M40-HC01510056-070039-5103-Y)
16	YC.ST.LL000330	Screw (M40-HC01510056-070039-5103-Y)
17	YC.JG.ZS003466	Landing Gear Fixing Piece (Rear Left)
18	YC.JG.ZS003465	Landing Gear Fixing Piece (Front Left)
19	YC.JG.ZS003464	Landing Gear Fixing Piece (Front Right)
20	YC.JG.XW000111	Landing Gear Crossbeam (Front)




6. Cable Distribution Module

No.	Material Number	Material Name
1	YC.ST.LL000122	Screw M25-HC00780040-040020-5108-N
2	YC.JG.MY000797	Barometer Curving Connector
3	YC.QT.QT000167	Barometer Waterproof Permeability Film
4	YC.JG.ZS002301	Barometer Outer Shell
5	BC.AG.PP000354	Barometer Board
6	YC.PM.QT000137	Barometer Protection Foam
7	YC.ST.LL000236	T20-PC00400040-040010-5103-N
8	YC.WJ.L00870	Screw M30-HC060060-55-85
9	YC.JG.MY000699	Barometer Module Sealing Ring
10	YC.JG.MY001046	Aerial-Electronics Module Sealing Ring
11	YC.WJ.L00870	Screw M30-HC060060-55-85
12	BC.AG.SS000674	Aerial-Electronics System Module (CN)
12	BC.AG.SS000837	Aerial-Electronics System Module (H)
12	BC.AG.SS000838	Aerial-Electronics System Module (L)
13	YC.WJ.L00870	Screw M30-HC060060-55-85
14	BC.AG.SS000675	RF Module
15	YC.JG.MY001045	RF Sealing Ring
16	YC.JG.MQ001294	Aerial-Electronics Module RF Thermal Conductive Pad
17	BC.AG.SS000676	Cable Distribution Board Module
18	YC.JG.MY000757	Damping Pad
19	YC.ST.LL000226	M30-HC01450080-100020-5103-Y
20	YC.XC.XX001014	FPV Camera Signal Cable
21	YC.ST.LL000122	Screw M25-HC00780040-040020-5108-N
22	YC.WJ.LL000235	M20-HPW00600060-065016-5103-Y_02
23	YC.JG.MY000389	Type-C Port Waterproof Cover



7. Cables


No.	Material Number	Material Name
1	YC.WJ.LL000340	Screw (M30-HC01600120-057030-0323-Y)
2	YC.JG.ZS003453	Propulsion Cable Clip
3	YC.XC.DD000576	Front Arm ESC Power Adapter Cable
4	YC.XC.XX000997	Throttle Cable (Cable Distribution Board-Spraying Module)
5	YC.XC.TT000132 RTK	Coaxial Cable
6	YC.DZ.AA000325	SDR Antenna (Rear)
7	BC.AG.SS000673	Weighing Sensor Module
8	YC.JG.MY001011	Weighing Sensor Rubber Cover
9	YC.XC.DD000576	Front Arm ESC Power Adapter Cable
10	YC.XC.TT000132 RTK	Coaxial Cable
11	YC.DZ.AA000325	SDR Antenna (Rear)
12	YC.XC.XX001009	Communicate Cable (Cable Distribution Board-Spraying Module)
13	YC.XC.XX000993	Front Atomized Sprinkler Power Cable
14	YC.ST.LL000122	Screw M25-HC00780040-040020-5108-N




8. Tank I

No.	Material Number	Material Name
1	YC.JG.CS000016	Spray Tank (40L)
2	For details, please refer to Impeller Pump	
3	Please refer to the Flow Meter for details	

9. Tank II




No.	Material Number	Material Name
1	YC.WJ.L00876	Screw M40-HC060060-55-85
2	YC.JG.ZS003392	Impeller Pump Bracket
3	YC.JG.MY000687	Spray Tank Y-tee Part Sealing Ring
4	YC.JG.ZS002235	Quick-Release Filter
5	YC.JG.ZS002250	Spray Tank Cover Waterproof Permeability Cover
6	YC.JG.ZS002251	Spray Tank Cover
7	YC.JG.MY000678	Spray Tank Cover Waterproof Permeability Film
8	YC.JG.MY000679	Spray Tank Cover Sealing Ring
9	YC.JG.ZS001085	Spray Tank Inlet Filter
10	BC.AG.SS000709	Liquid Level Gauge Sensor Module
11	YC.BZ.RB000011	Spread Tank Lanyard
12	YC.WJ.L00876	Screw M40-HC060060-55-85
13	YC.JG.ZS002237	Liquid Level Gauge Bracket
14	YC.WJ.LL000211	M30-HC02050080-070020-5103-Y_01
15	YC.JG.MY000845	Spray Tank Y-tee Part Sealing Ring
16	YC.JG.ZS002233	Water Outlet Rotation Cover
17	YC.JG.ZS002232	Spray Tank Y-tee Part
18	YC.JG.MY000687	Spray Tank Y-tee Part Sealing Ring
19	YC.SJ.WS002423	Spray Tank_Spray Tank Cover Ring
20	YC.JG.ZS000984	Flow Meter Bracket
21	YC.WJ.LL000188	Screw M40-HC00750040-060030-5103-N_01
22	YC.SJ.J01186	Spray Tank_Filter Rubber Ring
23	YC.JG.ZS002429	Filter With 50 Holes
24	YC.XJ.QT000194	Spray Tank_Liquid Level Meter Installation Nut
25	YC.JG.ZS003393	Spray Tank Cable Clip
26	YC.WJ.L00876	Screw M40-HC060060-55-85
27	YC.SJ.WS002412	Spray Tank_Liquid Level Meter Installation Nut
28	BC.AG.SS000471	Spray Tank Liquid Level Meter



10. Impeller Pump

No.	Material Number	Material Name
1	YC.WJ.L00870	Screw M30-HC060060-55-85
2	YC.JG.ZS002389	Impeller Pump Protective Hood
3	BC.AG.SS000543	Impeller Pump Motor
4	YC.JG.MY000704	Motor Sealing Ring
5	YC.JG.MY000712	Centrifugal Valve Rubber Pad
6	YC.JG.ZS003418	Impeller Pump Shell
7	YC.JG.ZS002233	Water Outlet Rotation Cover
8	YC.JG.MY001052	Pump Sealing Ring
9	YC.XC.XX001002	Spraying Signal Cable
10	YC.JG.MY001053	Y-tee Part Sealing Pad
11	YC.JG.ZS003420	Impeller Pump Curving Connector
12	YC.XJ.QT000350	Pump_Connector Sealing Ring
13	YC.JG.QX002485	Anti-Wear Gasket
14	YC.JG.MY000832	Damping Pad
15	YC.WJ.LL000138	Screw M25-HC00400040-050020-0003-N
16	YC.JG.ZS003417	Impeller Pump Spacing Sleeve
17	BC.AG.SS000710	Impeller Pump Module



11. Flow Meter Module


No.	Material Number	Material Name
1	YC.XC.XX001004	Flow Meter Signal Cable
2	YC.JG.ZS002255	Hose Nut
3	YC.JG.JS000032	Flow Meter Water Inlet Hose
4	BC.AG.SS000712.01	Flow Meter Module (Incl. Signal Cable)
5	YC.JG.JS000033	Flow Meter Water Outlet Hose
6	YC.JG.ZS003594	Thumb Nut
7	YC.ST.LL000122	Screw M25-HC00780040-040020-5108-N
8	YC.JG.ZS003478	Hose Curving Connector (M15)

12. M1 Aircraft Arm



No.	Material Number	Material Name
	YC.WJ.L01234	Screw M40-HC080080-68-85
	BC.AG.SS000700	ESC Module
	YC.JG.MY000399	Cable Sealing Pad
	YC.WJ.L00870	Screw M30-HC060060-55-85
	YC.JG.MY000397	Three Phase Cable Sealing Silicone Rubber
	YC.ST.LL000326	Screw (M50-HF01900080-095050-5103-Y)
	YC.JG.MY001062	Hose Rubber Sleeve
	YC.JG.QX003096	Motor Base (Upper)
	YC.ST.LL000380	Screw (M20-PC01200100-040010-0323-Y)
0	YC.JG.QX003097	Motor Base (Lower)
1	BC.AG.SS000668	10033 Propulsion Motor
2	YC.ST.LL000122	Screw M25-HC00780040-040020-5108-N
3	YC.JG.FP000028	Motor Cover
4	YC.WJ.LL000213	M30-HT01930060-110025-5103-Y
5	YC.ST.LL000380	Screw (M20-PC01200100-040010-0323-Y)
6	YC.ST.LL000208	M20-TC00700060-033010-0004-Y
7	YC.JG.ZS002379	Motor Upper Cover
8	YC.WJ.L00871	Screw M30-HC100100-55-85
9	YC.WJ.L00877	M3 Nut
0	YC.JG.ZS003557	Anti-Wear Sleeve
1	YC.WJ.L00871	Screw M30-HC100100-55-85
2	YC.JG.LD000039	Aircraft Arm Fixing Screw
3	YC.JG.ZS002278	In-Position Detector Bracket
4	YC.JG.QX002314	Aircraft Arm Fixing Screw Bolt
5	BC.AG.SS000696	M1 Aircraft Arm (Front Right)
5	BC.AG.SS000844	M1 Aircraft Arm (Front Right) (H)
5	BC.AG.SS000697	M2 Aircraft Arm (Front Left)
5	BC.AG.SS000845	M2 Aircraft Arm (Front Left) (H)
6	YC.XC.DD000573	M1&M2 Aircraft Arm ESC Composite Cable
7	YC.ST.LL000148	M40-HC01400140-070039-4105-Y
8	YC.JG.QX003012	Locking Piece Handle
9	YC.JG.ZS003560	Locking Piece Handle Rubber Sleeve
0	YC.JG.QX001243	Locking Piece_Handle Connecting Rod Shaft
1	BC.AG.SS000701	Buckle Module
2	YC.JG.BJ002409	E-Shaped Circlip (6 mm)
3	YC.JG.TT000165	Buckle Torsion Spring
4	YC.JG.QX003014	Buckle Rotation Shaft
5	YC.JG.QX002089	Locking Piece Aircraft Arm Shaft
6	YC.JG.LD000041	Locking Piece Fixing Screw Bolt
7	YC.WJ.LM000044	M60-HX100060-5103_01
8	YC.JG.QX002088	Locking Piece Connection Rod

13. M3 Aircraft Arm




No.	Material Number	Material Name
1	YC.JG.MY000397	Three Phase Cable Sealing Silicone Rubber
2	YC.WJ.L00870	Screw M30-HC060060-55-85
3	BC.AG.SS000700	ESC Module
4	YC.JG.MY000399	Cable Sealing Pad
5	YC.ST.LL000326	Screw (M50-HF01900080-095050-5103-Y)
6	YC.JG.MY001062	Hose Rubber Sleeve
7	YC.JG.QX003096	Motor Base (Upper)
8	Please refer to the spray boom for details.	
9	YC.JG.QX003097	Motor Base (Lower)
10	BC.AG.SS000668	10033 Propulsion Motor
11	YC.ST.LL000380	Screw (M20-PC01200100-040010-0323-Y)
12	YC.ST.LL000122	Screw M25-HC00780040-040020-5108-N
13	YC.JG.CS000020	Elbow Connector (180 Degrees)
14	YC.JG.ZS003460	Hose Nut (M15)
15	YC.JG.QX002177	Lower Propeller Adapter
16	YC.JG.FP000028	Motor Cover
17	YC.WJ.LL000213	M30-HT01930060-110025-5103-Y
18	YC.ST.LL000380	Screw (M20-PC01200100-040010-0323-Y)
19	YC.ST.LL000208	M20-TC00700060-033010-0004-Y
20	YC.JG.ZS002379	Motor Upper Cover
21	YC.WJ.L00871	Screw M30-HC100100-55-85
22	YC.WJ.L00877	M3 Nut
23	YC.JG.ZS003557	Anti-Wear Sleeve
24	YC.WJ.L00871	Screw M30-HC100100-55-85
25	YC.JG.LD000039	Aircraft Arm Fixing Screw
26	YC.JG.ZS002278	In-Position Detector Bracket
27	YC.JG.QX002314	Aircraft Arm Fixing Screw Bolt
28	YC.JG.JS000030	Aircraft Arm Hose
29	BC.AG.SS000698	M3 Aircraft Arm (Rear Left)
29	BC.AG.SS000846	M3 Aircraft Arm (Rear Left) (H)
29	BC.AG.SS000699	M4 Aircraft Arm (Rear Right)
29	BC.AG.SS000847	M4 Aircraft Arm (Rear Right) (H)
30	YC.JG.ZS003594	Thumb Nut
31	YC.XC.DD000572	M3&M4 Aircraft Arm ESC Composite Cable
32	YC.JG.QX002089	Locking Piece Aircraft Arm Shaft
33	YC.JG.QX003012	Locking Piece Handle
34	YC.JG.ZS003560	Locking Piece Handle Rubber Sleeve
35	YC.JG.QX001243	Locking Piece_Handle Connecting Rod Shaft
36	BC.AG.SS000701	Buckle Module
37	YC.JG.BJ002409	E-Shaped Circlip (6 mm)
38	YC.JG.TT000165	Buckle Torsion Spring
39	YC.JG.QX003014	Buckle Rotation Shaft
40	YC.ST.LL000148	M40-HC01400140-070039-4105-Y
41	YC.JG.LD000041	Locking Piece Fixing Screw Bolt
42	YC.WJ.LM000044	M60-HX100060-5103_01
43	YC.JG.QX002088	Locking Piece Connection Rod
44	YC.WJ.L01234	Screw M40-HC080080-68-85



14. Spray Lance

No.	Material Number	Material Name
1	BC.AG.SS000565	Centrifugal Motor
2	BC.AG.SS000752	Spray Lance Nut
3	YC.JG.ZS003399	Spray Lance Shell (Rear)
4	YC.JG.MY000712	Centrifugal Valve Rubber Pad
5	YC.JG.MY000704	Motor Sealing Ring
6	YC.WJ.L00870	Screw M30-HC060060-55-85
7	BC.AG.SS000708	Atomized Sprinkler Lower Cover
8	YC.WJ.LL000138	Screw M25-HC00400040-050020-0003-N
9	BC.AG.SS000707	Solenoid Valve Module
10	YC.XC.XX001000	Atomized Sprinkler Adapter Cable (Rear)
11	YC.JG.JS000031	Spray Lance Bellow Hose (Rear)
12	YC.JG.ZS003460	Hose Nut (M15)
13	YC.JG.ZS003460	Hose Nut (M15)
14	YC.JG.JS000041	Spray Lance Soft Hose (Rear)
15	YC.WJ.LL000138	Screw M25-HC00400040-050020-0003-N
16	YC.JG.ZS003459	Spinner Disk Upper Disk
17	YC.JG.FM000092	Centrifugal Sprinkler Thumb Nut
18	YC.JG.ZS002289	Centrifugal Sprinkler Spring Bracket
19	YC.JG.ZS003458	Spinner Disk Lower Disk



15. Propeller

No.	Material Number	Material Name
1	YC.JG.ZS005016	Upper Propeller (CCW)
1	YC.JG.ZS005016	Upper Propeller (CCW)
2	YC.JG.ZS003829	Propeller Gasket
3	YC.JG.ZS005018	Lower Propeller (CCW)
3	YC.JG.ZS005018	Lower Propeller (CCW)
4	YC.JG.QX002177	Lower Propeller Adapter
5	YC.ST.LL000209	M50-HF01430102-116041-0003-Y
6	YC.JG.QX002715	Upper Propeller Adapter
7	YC.JG.ZS005017	Upper Propeller (CW)
7	YC.JG.ZS005017	Upper Propeller (CW)
8	YC.JG.ZS005019	Lower Propeller (CW)
8	YC.JG.ZS005019	Lower Propeller (CW)
9	YC.BZ.RB000090	Propeller Holder (Beige)