

T100 Parts



[Flow Meter 1](#)

[Impeller Pump](#)

[Spray Tank 1](#)

[Spray Tank 2](#)

[Spray Boom](#)

[Landing Gear 1](#)

[Landing Gear 2](#)

[Landing Gear 3](#)

[Cable Distribution](#)

[Front Frame 1](#)

[Front Frame 2](#)

[Middle Frame](#)


[Arms Large Front](#)

[Short Arms](#)

[M1 & M3 Arms](#)


[Motor](#)

[Propeller](#)



Flow Meter Module

No.	Material Number	Material Name
1	YC.JG.ZS006171	Thumb Nut
2	YC.JG.ZS006199	Flow Meter Adapter
3	YC.JG.MY001790	Flow Meter Adapter Sealing Ring
4	BC.AG.SS001031	Flow Meter Module
5	YC.JG.ZS006165	Hose Nut
6	YC.JG.JS000080	Flow Meter Water Outlet Hose
7	YC.JG.ZS006171	Thumb Nut
8	YC.JG.ZS006170	One-Way Valve
9	YC.JG.MY001774	One-Way Valve Sealing Ring
10	YC.JG.MY001775	Valve Core Sealing Ring
11	YC.JG.TT000285	One-Way Valve Spring
12	YC.JG.ZS006644	Hose Y-tee Part
13	YC.JG.ZS006115	Single Connector Rubber Stopper
14	YC.JG.JS000088	Flow Meter Water Inlet Hose



Impeller Pump


No.	Material Number	Material Name
1	YC.JG.MY001315	Sealing Ring (OD=31.4 mm)
2	YC.JG.MY001828	Motor Sealing Ring (OD= 46.8 mm)
3	BC.AG.SS001033	Impeller Pump Motor
4	YC.JG.ZS006166	Pump Shell
5	YC.JG.ZS006175	Impeller Pump Curving Connector
6	YC.JG.MY001830	Curving Connector Sealing Ring
7	YC.JG.MY001327	Ceramic Rubber Pad
8	YC.JG.FM000157	Ceramic Gasket
9	YC.WJ.L01234	Screw M40-HC080080-68-85
10	YC.JG.ZS002233	Water Outlet Rotation Cover
11	YC.XC.XX001409	Sprinkler Adapter Cable
12	BC.AG.SS001032	Impeller Module
13	YC.JG.MY001053	Y-tee Part Sealing Pad
14	YC.JG.MY001052	Pump Sealing Ring
15	YC.JG.ZS006167	Spacing Sleeve
16	YC.ST.LL000717	Screw (M25-HC00500050-050020-5104-N)

1



Spray Tank 1

No.	Material Number	Material Name
1	YC.JG.CS000050	Spray Tank (100L)




Spray Tank 2

No.	Material Number	Material Name
1	YC.ST.AS000053	Aluminum Clip
2	YC.ST.AS000043	Spray Tank Lanyard
3	YC.JG.ZS002250	Spray Tank Cover Waterproof Permeability Cover
4	YC.JG.MY000678	Spray Tank Cover Waterproof Permeability Film
5	YC.JG.ZS006110	Spray Tank Cover
6	YC.JG.MY001721	Dosing Part Rubber Cover
7	YC.ST.LL000698	Screw (M25-HCW00960040-055020-5103-Y)
8	YC.JG.MY001811	16-pin Connector Sealing Ring
9	YC.ST.LL000698	Screw (M25-HCW00960040-055020-5103-Y)
10	YC.JG.ZS006291	16-pin Connector Plastic Cover
11	YC.WJ.L01234	Screw M40-HC080080-68-85
12	BC.AG.SS001068	Payload Control Board
13	YC.JG.ZS006858	20-pin Connector Plastic Cover
14	YC.ST.LL000698	Screw (M25-HCW00960040-055020-5103-Y)
15	YC.JG.MY001989	20-pin Connector Sealing Ring
16	YC.JG.ZS006360	Impeller Pump Bracket
17	YC.WJ.L01234	Screw M40-HC080080-68-85
18	YC.JG.ZS005454	Filter With 50 Holes
19	YC.JG.ZS005453	Spray Tank Y-tee Part Nut
20	YC.JG.MY000687	Spray Tank Y-tee Part Sealing Ring
21	YC.SJ.J01186	Spray Tank_Filter Rubber Ring
22	YC.JG.MY000687	Spray Tank Y-tee Part Sealing Ring
23	YC.JG.MY000845	Damping Rubber Pad
24	YC.JG.ZS002232	Spray Tank Y-tee Part
25	YC.JG.ZS002233	Water Outlet Rotation Cover
26	YC.JG.ZS004726	Liquid Level Gauge Nut
27	YC.JG.MY001801	Liquid Level Gauge Base Sealing Ring
28	YC.JG.ZS006114	Liquid Level Gauge Base
29	YC.WJ.L01234	Screw M40-HC080080-68-85
30	YC.JG.ZS004712	Flow Meter Bracket
31	BC.AG.SS001122	Liquid Level Gauge Module
32	YC.JG.ZS006843	Liquid Level Gauge External Hose Rubber Stopper
33	YC.WJ.L01234	Screw M40-HC080080-68-85
34	YC.XC.XX001398	Liquid Level Gauge Signal Cable
35	YC.JG.JS000085	Liquid Level Gauge External Hose
36	BC.AG.SS001121	Liquid Level Gauge Hose Module
37	YC.WJ.L01234	Screw M40-HC080080-68-85
38	YC.XC.XX001396	Delivery Pump Flow Meter Cable
39	YC.JG.ZS006111	Spray Tank Inlet Filter
40	YC.JG.MY001720	Spray Tank Cover Sealing Ring






Spray Boom

No.	Material Number	Material Name
1	BC.AG.SS001028	Centrifugal Motor
2	YC.JG.ZS006216	Sprinkler Funnel
3	YC.WJ.L01549	M25-HC060060-45-85
4	YC.JG.MY001052	Pump Sealing Ring
5	YC.JG.MY001829	Sprinkler Inner Sealing Ring (OD=23.6 mm)
6	YC.JG.ZS006215	Sprinkler Funnel Bracket
7	YC.JG.ZS006807	Spray Lance Bottom Shell
8	YC.JG.ZS006356	Spray Lance Outer Shell
9	YC.WJ.LL000232	M40-HC01000100-072028-5103-N_01
10	YC.JG.JS000067	Sprinkler Soft Hose
11	BC.AG.SS001073	Solenoid Valve Module
12	YC.JG.ZS006592	Spring Fixing Piece
13	YC.JG.BJ003348	Circlip
14	YC.JG.ZS006357	Spray Lance Shaft Sleeve
15	YC.WJ.LM000044	M60-HX100060-5103_01
16	YC.JG.QX004533	Spray Lance Shaft
17	YC.JG.TT000275	Compression Spring
18	YC.JG.ZS006594	Spray Lance Shaft Connector
19	YC.WJ.LL000232	M40-HC01000100-072028-5103-N_01
20	YC.JG.ZS006593	Spray Lance Slider
21	YC.JG.ZS006808	Spray Lance Shaft Connector Shell (M2 & M4)
22	YC.JG.ZS006809	Spray Lance Shaft Connector Shell (M1 & M3)
23	YC.JG.ZS006171	Thumb Nut
24	YC.JG.JS000077	Aircraft Arm Hose
25	YC.JG.QX004534	Spray Lance Support Rod
26	YC.JG.ZS006171	Thumb Nut
27	YC.JG.MY001828	Motor Sealing Ring (OD= 46.8 mm)
28	YC.XC.XX001460	Centrifugal Spray Lance Cable
29	YC.JG.MY001829	Sprinkler Inner Sealing Ring (OD=23.6 mm)
30	YC.JG.ZS006219	Centrifugal Sprinkler Lower Disk
31	YC.JG.ZS006218	Sprinkler Thumb Nut
32	YC.JG.ZS007737	Centrifugal Sprinkler Upper Disk
33	YC.WJ.L01549	M25-HC060060-45-85




Landing Gear 1

No.	Material Number	Material Name
1	YC.JG.BJ004111	Landing Gear Aluminum Tube
2	YC.JG.ZS006786	Landing Gear Hose Clamp
3	YC.ST.LL000543	Screw T30-HC01000100-057030-5103-N
4	YC.JG.MY002074	Anti-collision Soft Rubber
5	YC.JG.ZS006801	Landing Gear Payload Cable Clamp B
6	YC.JG.ZS006786	Landing Gear Hose Clamp
7	YC.ST.LL000730	Screw (M40-HC01400115-085047-4203-Y)
8	YC.JG.ZS006655	Bottom Rubber Pad
9	YC.ST.LM000107	M40-HX088065-5103




Landing Gear 2

No.	Material Number	Material Name
1	YC.XC.XX001470	Spotlight Signal Cable
2	YC.JG.ZS006719	Spotlight Bracket
3	YC.ST.LL000730	Screw (M40-HC01400115-085047-4203-Y)
4	YC.XC.DD000815	Payload Adapter Cable
5	YC.JG.ZS006708	Landing Gear Y-tee Part Cover
6	YC.ST.LL000731	Screw (M40-HC04800220-088047-5103-Y)
7	YC.ST.LM000107	M40-HX088065-5103
8	YC.ST.LL000730	Screw (M40-HC01400115-085047-4203-Y)
9	YC.JG.ZS006709	Landing Gear Spray Lance Connector
10	YC.ST.LL000731	Screw (M40-HC04800220-088047-5103-Y)
11	YC.ST.LM000107	M40-HX088065-5103
12	YC.ST.LL000730	Screw (M40-HC01400115-085047-4203-Y)
13	YC.JG.ZS006693	Landing Gear Crossbeam (Rear)
14	YC.XC.XX001523	Rear Radar Signal Cable (Short)
15	BC.AG.SS001107	Rear Radar Module
16	YC.WJ.L00871	Screw M30-HC100100-55-85
17	YC.JG.ZS007274	Rear Radar Bracket
18	YC.WJ.L00871	Screw M30-HC100100-55-85
19	YC.ST.LL000341	Screw (M40-HCW01000070-070040-5104-N)
20	YC.JG.ZS006630	Spray Tank C-Type Mounting Piece
21	YC.JG.ZS006692	Landing Gear Crossbeam (Front)
22	YC.WJ.L00871	Screw M30-HC100100-55-85
23	BC.AG.SS001020	Spotlight




Landing Gear 3

No.	Material Number	Material Name
1	YC.ST.LM000107	M40-HX088065-5103
2	YC.ST.LL000607	Screw M40-HC04000140-070040-5103-Y
3	YC.ST.LL000730	Screw (M40-HC01400115-085047-4203-Y)
4	YC.JG.ZS006654	Landing Gear C-Type Connector
5	YC.JG.XW000215	Landing Gear Top Crossbar
6	YC.ST.LL000341	Screw (M40-HCW01000070-070040-5104-N)
7	YC.JG.ZS007112	Spray Tank Top Mounting Piece
8	YC.JG.ZS005949	Frame Connector (Right)
9	YC.JG.MY001953	Anti-Collision Pad
10	YC.JG.ZS006800	Payload Cable Clamp
11	YC.WJ.LL000232	M40-HC01000100-072028-5103-N_01
12	YC.JG.MY002073	Landing Gear Hole Plug Rubber
13	YC.JG.ZS006707	Buckle Hook Cover
14	YC.ST.LL000730	Screw (M40-HC01400115-085047-4203-Y)
15	YC.JG.QX004626	Buckle Hook
16	YC.JG.ZS005948	Frame Connector (Left)




Cable Distribution Module

No.	Material Number	Material Name
1	YC.JG.MQ003711	Thermal Conductive Pad (11×42 mm)
2	BC.AG.SS001091	Cable Distribution Board Module
3	YC.JG.QX002312	Damping Pad B
4	YC.JG.ZS006682	Damping Pad A
5	YC.JG.MY000389	Type-C Port Waterproof Cover
6	YC.ST.LL000122	Screw M25-HC00780040-040020-5108-N
7	BC.AG.SS001131	Aerial-Electronics Module (Overseas)
8	YC.WJ.L00868	Screw M30-HC080080-55-85
9	YC.SJ.S00717	Vent Trap
10	YC.JG.MQ003708	Thermal Conductive Pad (162×23.5 mm)
11	YC.JG.MQ002623	Thermally Conductive Pad (53.1 x 12.9 mm)
12	YC.JG.MY001920	Aerial-Electronics Module Sealing Ring
13	YC.QT.QT000167	Barometer Waterproof Permeability Film
14	YC.ST.LL000122	Screw M25-HC00780040-040020-5108-N
15	YC.JG.MY001918	Barometer Tube
16	YC.WJ.LL000235	M20-HPW00600060-065016-5103-Y_02
17	YC.ST.LL000718	Screw (M40-HC01750080-100034-5103-Y)




Front Frame 1

No.	Material Number	Material Name
1	BC.AG.SS001103	Front Frame Aluminum Tube
2	YC.ST.LL000013	Screw M40-HC01400140-070039-0003-Y
3	YC.JG.ZS006714	Power Cable Clamp B0
4	YC.JG.MQ003801	FPV Sealing Foam
5	YC.JG.ZS006589	FPV Bracket
6	YC.ST.LL000730	Screw (M40-HC01400115-085047-4203-Y)
7	YC.JG.MQ003860	Wear-Resistant Foam (77×30)
8	YC.JG.ZS006590	Laser Radar Insulation Spacer
9	YC.ST.LL000730	Screw (M40-HC01400115-085047-4203-Y)
10	YC.JG.YZ001068	Laser Radar Bracket
11	YC.ST.LL000726	Screw (M25-HC00580058-050025-5103-Y)
12	YC.JG.ZS006649	Power Distribution Board Protective Cover
13	YC.ST.LL000726	Screw (M25-HC00580058-050025-5103-Y)
14	BC.AG.SS001090	Power Distribution Board Module
15	YC.ST.LL000699	Screw (M50-HC01300107-087050-5103-N)
16	YC.ST.LL000697	Screw (M40-HC03800090-135020-5103-Y)
17	YC.JG.TT000282	Power Distribution Module Spring
18	YC.JG.ZS006775	Power Distribution Module Spring Pad
19	YC.ST.LL000699	Screw (M50-HC01300107-087050-5103-N)
20	YC.JG.ZS004560	Power Distribution Board Dustproof Cover
21	YC.JG.MQ003697	Thermal Conductive Pad (49.6×35.6 mm)
22	YC.ST.LL000551	Screw (M20-PC01200100-040010-0323-Y)
23	YC.XC.XX001498	Laser Radar Signal Cable
24	BC.AG.SS001166	Laser Radar Module (Overseas)
24-1	YC.OC.PA000059	Laser Radar cover
24-2	YC.JG.MY000651	Optical Window Sealing Ring
24-3	YC.JG.MQ003930	Pressing Ring
24-4	YC.JG.QX004623	Locking Ring
24-5	YC.XC.XX001498	Laser Radar Signal Cable
25	YC.ST.LL000730	Screw (M40-HC01400115-085047-4203-Y)
26	YC.JG.YZ001069	Front Radar Bracket
27	YC.JG.ZS006715	Power Cable Clamp B1



Front Frame 2

No.	Material Number	Material Name
1	YC.WJ.L00868	Screw M30-HC080080-55-85
2	YC.JG.ZS006627	RTK Bracket
3	BC.AG.SS001034	RTK Antenna Module
3-1	YC.ST.LL000236	Screw (T20-PC00400040-040010-5103-N)
3-2	YC.JG.ZS006626	RTK Lower Cover
3-3	YC.JG.MY001919	RTK Sealing Ring
3-4	YC.WJ.LL000396	Screw (T20-PC00400040-040010-0323-N)
4	YC.JG.MY001898	RTK Rubber Ring
6	YC.JG.MQ003696	Front Radar Sealing Foam
7	YC.JG.ZS006459	Front Top Shell
8	YC.WJ.L00871	Screw M30-HC100100-55-85
9	YC.JG.MY001896	Cable Rubber Stopper
10	YC.JG.ZS006460	Front Shell Bottom Cover
11	YC.ST.LL000013	Screw M40-HC01400140-070039-0003-Y
12	YC.DZ.AA000462	SDR Antenna (Front)
13	YC.XC.XX001427	Downward Radar Signal Cable
14	YC.WJ.L00871	Screw M30-HC100100-55-85
15	BC.AG.SS001087	Downward Radar Module
16	YC.XC.XX001419	FPV Signal Cable
17	YC.WJ.L00870	Screw M30-HC060060-55-85
18	BC.AG.SS001021	FPV Module
19	YC.XC.XX001467	Front Radar Signal Cable
20	YC.ST.LL000013	Screw M40-HC01400140-070039-0003-Y
21	YC.WJ.L00868	Screw M30-HC080080-55-85
22	YC.JG.ZS006690	Front Radar Base Bracket
23	YC.JG.ZS006691	Quad Vision Sensor Cable Decorative Cover
24	BC.AG.SS001167	Front Radar Module (Overseas)
25	YC.JG.MQ003829	Radar Protective Foam
26	BC.AG.SS001093	Quad-Fisheye Vision Sensor Module
27	YC.WJ.LL000211	M30-HC02050080-070020-5103-Y_01
28	YC.JG.MQ003804	Quad Vision Sensor Cover Plate




Middle Frame

No.	Material Number	Material Name
1	YC.ST.LL000013	Screw M40-HC01400140-070039-0003-Y
2	YC.JG.QX004627	Buckle Support Base
3	YC.JG.QX004628	Pin Shaft (29.7 mm)
4	YC.JG.BJ003137	E-Type Circlip (OD=9 mm)
5	BC.AG.SS001094	Middle Frame Buckle Module
6	YC.ST.LL000542	Screw M30-HC00700054-058012-4203-Y
7	YC.JG.ZS006716	SDR Cable Clamp B0
8	YC.JG.ZS006685	Airframe Cable Cover
9	BC.AG.SS001105	Middle Frame Aluminum Tube (Right)
10	YC.JG.ZS006713	Airframe Cable Clamp
11	YC.XC.XX001488	In-Position Detector Cable
12	BC.AG.SS001104	Middle Frame Aluminum Tube (Left)
13	YC.JG.ZS006717	SDR Cable Clamp B1
14	BC.AG.SS001106	Rear Frame Aluminum Tube
15	YC.JG.ZS007292	Airframe Screw Cover
16	YC.ST.LL000720	Screw (M60-HT01530110-113060-5103-Y)
17	BC.AG.SS001095	Battery Slider Module
18	YC.JG.MY001504	Battery Bracket Rubber Pad
19	YC.ST.LL000730	Screw (M40-HC01400115-085047-4203-Y)




Short Arms

No.	Material Number	Material Name
1	BC.AG.SS001097	Large Aircraft Arm (Front)
2	YC.JG.QX004654	Aircraft Arm Fixing Nut
3	YC.JG.QX004581	Aircraft Arm Fixing Screw Bolt
4	YC.DZ.AA000573	SDR Antenna (Rear)
5	YC.JG.ZS006676	SDR Bracket
6	YC.WJ.L00870	Screw M30-HC060060-55-85
7	BC.AG.SS001098	Large Aircraft Arm (Rear)
8	YC.JG.FM000215	Aircraft Arm Insert
9	YC.WJ.L00870	Screw M30-HC060060-55-85
10	YC.ST.LL000721	Screw (M60-HC02170160-110078-5103-Y)



M1 & M3 Arm

No.	Material Number	Material Name
1	BC.AG.SS001189	ESC Module
2	YC.ST.LL000732	Screw (M30-HC00930058-060030-5103-Y)
3	YC.JG.ZS006704	Motor Cable Clamp
4	YC.JG.ZS006705	Aircraft Arm End Cap
5	YC.JG.MY001951	Aircraft Arm Anti-Collision Pad
6	YC.ST.LL000732	Screw (M30-HC00930058-060030-5103-Y)
7	BC.AG.SS001100	M1 & M3 Small Aircraft Arm
7-2	BC.AG.SS001101	M2 & M4 Small Aircraft Arm
8	YC.WJ.LL000232	M40-HC01000100-072028-5103-N_01
9	YC.JG.ZS006702	Aircraft Arm ESC Base Fixing Piece
10	BC.AG.SS001099	Aircraft Arm Buckle Module
11	YC.ST.LM000026	Nut (M50-HN078050-5103)
12	YC.JG.TT000278	Buckle Torsion Spring
13	YC.JG.LD000124	Pin Shaft (57.1 mm)
14	YC.JG.ZS006673	Aircraft Arm Limit Block
15	YC.ST.LL000771	Screw (M50-HC01000082-087052-5103-Y)
16	YC.JG.ZS006701	Aircraft Arm ESC Base
17	YC.JG.MQ002156	Duct Tape
18	YC.WJ.L00871	Screw M30-HC100100-55-85
19	YC.XC.XX001468	Aircraft Arm Signal Cable (Front)
19-2	YC.XC.XX001469	Aircraft Arm Signal Cable (Rear)
20	YC.JG.ZS006620	ESC Three-Phase Waterproof Cover
21	YC.XC.DD000812	Aircraft Arm Propulsion Cable (Front)
21-2	YC.XC.DD000813	Aircraft Arm Propulsion Cable (Rear)
22	YC.ST.LL000667	Screw (M40-HCW01150115-070040-5103-N)
23	YC.JG.MY001908	ESC Three-Phase Waterproof Cover Rubber Seal
24	YC.WJ.L00871	Screw M30-HC100100-55-85
25	YC.ST.LL000667	Screw (M40-HCW01150115-070040-5103-N)
26	YC.JG.MY001907	ESC Waterproof Seal Plug
27	YC.WJ.LL000232	M40-HC01000100-072028-5103-N_01



Motor

No.	Material Number	Material Name
1	YC.ST.LL000612	Screw (M30-HC00800080-055030-5103-Y)
2	YC.JG.ZS006779	Motor Cable Protective Cover
3	YC.ST.LL000612	Screw (M30-HC00800080-055030-5103-Y)
4	YC.JG.ZS006778	Motor Lower Cover
5	YC.JG.ZS007579	Motor Upper Cover
6	YC.ST.LL000439	Screw (M30-HC01600100-057030-5103-Y)
7	BC.AG.SS001102	15516 Motor
8	YC.BZ.TZ001713	15516 Motor Sticker
9	YC.ST.LL000696	Screw (M60-HC02000180-100080-4203-Y)



Propeller

No.	Material Number	Material Name
1	YC.ST.LM000115	Nut (M80-HX130087-5103)
2	YC.JG.QX004794	Propeller Clamp
3	YC.JG.ZS006404	Propeller Gasket
4	YC.JG.XW000291	Propeller (CCW)
5	YC.JG.XW000292	Propeller (CW)